



Key Override System Installation Instructions

The Key Override System is preset for use on the exterior side of right-handed doors.

For left-handed doors, remove large center screw using a #2 screwdriver.

Flip cartridge so (L) is visible.

Replace screw.

Install lock.

