



# AKE-5 Wiring Diagram



**INPUTS**

**OUTPUTS**  
All Outputs Are Grounding 250mA



- 1) Lock Code 559: Locks the Door, Arm Enabled, Arms the Keypad  
Lock Code 557: Locks the Door and Arms the Alarm  
Lock Code 555: Locks the Door and Activates 3 Digit Convenience Codes(if enabled)
- 2) Any Valid User Code Unlocks the Door and Arm Disabled.
- 3) Arm Enabled by Lock Codes 559 and 557  
Arm Disabled by any valid User Code.

Patents Pending. Specifications Subject to Change Without Notice

The AKE-5 Series is covered by a 3 year limited warranty against defects in materials and workmanship. Essex Electronics disclaims any and all damages or injuries that may result from the installation or use of this product.

Visit <http://www.keyless.com/PDF/GeneralWarranty.pdf> for more information.