


Instruction for changing combination and using the lock

1. Using Instruction (Look at pic.1)

- A. Turn the combination to center line "0" (the original combination is "00-0-0-0"), insert the rubber part "a" into the bottomeck, hold the lock base "b", turn the lock head "c" clockwise until the rubber "a" sit tightly to the bottomeck. Then turn the dial to a combination other than your individual code, now the bottle can not be opened.
- B. Opening the wine lock.
Turn the dial to the opening combination to the center line "0" (the original combination is "0-0-0-0"), hold the lock base "b", turn the lock head "c" anti-clockwise until the rubber "a" loosens in the bottomeck.



2. Instruction for changing combination (Look at pic. 2)

- A. In order to set an individual combination the lock needs to be in the opened position. Turn off the lock head "c", turn the lever "f" as shown in the picture. Turn the dial "d" to the center line "0" and set your desired combination. Then push the lever "f" back to its original position. Screw the Lock head onto the lock. Your combination is now set.
- B. Note: Please don't forget the new combination you just set, or you can't open the lock.

